	Issuing Entity: Dartron Industries, Inc	Bulletin # SR-5K-003
Dartron	P. O. Box 13114 Salem, Oregon 97309 Phone: 503-362-2341 Fax: 503-362-2536	Release Date:January 27, 2004Effective Date:January 27, 2004Supercedes:N/ACompletion Date:Before OperatingPage 1 of 3
	www.dartronrides.com	

SAFETY BULLETIN

Ride Manufacturer: Dartron Industries, Inc.	Affected Production Dates: 08/98 – 08/99
Ride Name: Cliff Hanger	Affected Serial #'s: 806081-5K, 807121-5K, 810061-5K
	810283-5K, 901011-5K, 902221-5K, 903021-5K,
	903272-5K, 905101-5K

Abstract of Issue: As a result of an incident involving a Cliff Hanger ride in Florida Dartron is now aware that after a combination of events the Car Hanger Stem to Arch Assembly joint could fail. For this reason Dartron is requiring that all Cliff Hanger rides have a back up device that will support the car and its passengers in the event of a separation of the Arch Assembly from the Stem. Tests conducted by Dartron demonstrate that the factory-installed Arch Assembly to Car joint back up cable will safely suspend the car and its passengers in the event of a failure of the Stem to Arch Assembly joint. To identify the joint see Page 2 of this Bulletin and for more information on the factory installed cable see Page 3 of this Bulletin.

The factory-installed cable is an approved back up device for the Stem to Arch Assembly joint. No action is required for Cliff Hanger rides with a factory-installed cable.

The Cliff Hanger rides listed above have a different back up device for the Arch Assembly to Car joint and do not have factory-installed cables. The above listed Cliff Hanger rides must install the back up device described in this Bulletin as a back up for the Arch Assembly to Stem joint.

<u>Reason for release</u>: To ensure that the Cliff Hanger rides not equipped with a factory approved cable retrofit the Dartron approved back up device described herein.

Action to be taken:

- 1. The retrofit back up devise must be ordered from Dartron Industries.
- 2. The back up devise consists of:
 - a) Arch Assembly to Stem strap.
 - b) Stem to Welded Pipe strap.

b) Cable that is inserted through the Arch Assembly and attached to the car. Cable does not enter the stem.

3. Install the Back Up device as shown on Page 2 of this Bulletin.



