



WISDOM INDUSTRIES, Ltd.

SAFETY BULLETIN

DATE: FEBRUARY 7, 2006
SUBJECT: TORNADO
COMPLIANCE TIME: 1 MONTH
❖ RIDE EFFECTED TORNADO
PARTS EFFECTED: LOWER HYDRAULIC LIFT
CYLINDER HINGE PIN

PROCEDURE:

1. Raise ride.
2. Install prop brace.
3. Lower ride until weight is fully on the prop brace.
4. Turn off main power.
5. Remove lower cylinder pin retaining bolt.
6. Remove hinge pin.
7. Measure from bottom of hole to outside of ear.
8. Pin must be within 1/8" of bottom of hole to bottomed out.
9. If pin is more than 1/8" from bottom of hole, contact Wisdom for a replacement pin. *(Have the indicated dimension available).
10. If pin is acceptable, reinstall pin.
11. Install retaining bolt with lock washer.
12. Repeat for second cylinder.

If you have any questions, contact Wisdom Industries, Ltd.
at 970-522-7515