

Number: 8 6-20-71

Superceeds:

Number:

Dates

Service Information

Ride: KIDDLE BOAT RIDE MODEL "C" 2

Subject ERECTION AND CARE

REFERENCES:

Blueprint KBC-100 Assembly Dwg. Blueprint KB-100-P Parts Number Dwg. Blueprint KT-101 Foundation Dwg.

"SUGGESTED CHEMICAL TREATMENT OF WATER"

ERECTION AND CARE OF KIDDLE BOAT RIDE MODEL "C"

Refer to print number KBC-100 for general arrangement of parts and to number KB-100-2 for part number identification and lubrication instructions.

Select a spot that is reasonably level, especially for the center of the ride and the tank assembly.

Place the circular centerpole (KB-117) into position so that the motor will be located near light pole #1 (Switch Pole) to suit operator's convenience.

Place the drive unit into position and bolt it down tightly after pinion (KA-147) is properly meshed with ring gear. Check the "V" belts on the drive for proper tension. These have been set correctly at the factory, but when new, adjustment should be made frequently until the initial stretch has been taken up. These are not to be too tight and need very little attention during the season. CAUTION: Any adjustment of the belt drive should be done with the motor. Do not change the position of the gear reducer.

Fasten the centerpole assembly KB-118 securely to the centerpole base assembly (KB-117) by means of the four studs. Position these assemblies so that their markings match:

Place the ring goar (KA-L53) on top of the 6" dia. Tiber collar of centerpole assembly (KB-L18).

Level the base (KB-117) and plumb the centerpole (KA-154-2) using shims under the circular base (KB-117) if necessary. On park tides, four 7/8" dia. holes are provided in the base ring (KB-117) which can be used for bolding down after leveling.

Factory and General Office. 4219 Irving. Box 2397 Wichita Kansas 67201

Area Gode (316) 942-7411

Sales Office:

103 Ross Ave., Dallas, Texas, 75202

Area Code (214) 742-3802

Use expansion bolts if ride is mounted on a concrete slab (KT-101)

Attach three centering rods (KB-115 and KB-116) over Eugs on base ting (KB-117) and to tank sections as shown on assembly drawing KBC-100. Bolt six tank sections expetier, after leveling each section as it is placed, using the level furnished with the ride.

Insert light and switch pole marked #1 into holes of the tank section located nearest to motor. Assemble remaining cornice uprights (KB-119).

The cornice sections are numbered according to the upright pipes to which they attach and must be put on in order of their numbers. Attach the head shields. The spot light brackets are also marked to suit the uprights. These must also be placed in their proper order. Then plug in all plugs to complete the circuit.

Attach the switch box to \$1 upright and make up the lead connections and connect. Twist lock connectors complete are furnished for these connections.

Spread tent top over the centerpole. Place the tent pole on top of the centerpole and raise the tent about halfway. When in this position hook the outside edge of the tent in the loops provided on the inside of the cornice; then raise the tent to its proper height.


Place 6 sweep arms (KB-113) between angles on sweep place (KB-112) between sweep arms (KB-113) and retain with 3/8" x 1 1/2" long cotter pins.


Fasten 6 boats (KB-106) to sweep arms with 1/2" x 4" long cotter pins.

CAUTION: The wiring on this ride has been arranged for a separate connection to the lights from that of the drive motor. The ride is designed to run can 60-cycle 220 volt current (or 110 volt). Satisfactory results might not be obtained on lines having considerable drop in voltage, especially when operating on 110 volt line, and to insure proper operation, voltage of 105 to 115 must be maintained:

Motor connections are for 220 volts when ride leaves factory. If 110 volt current must be used, motor connections must be changed to suit wiring diagram on motor nameplate.

Operate the lighting only on 110 volt, 60-cycle current.





ü