

OLSON DRUG

## SAFETY BULLETIN

DATE: FEBRUARY 7, 2006

RIDE: TORNADO


SUBJECT: LIFT ARM REINFORCEMENT

COMPLIANCE DATE: 1 MONTH WITH DAILY


INSPECTION UNTIL INSTALLED.

- 1. Install 4 reinforcing gussets on the Tornado lift arm.
- 2. Clean area where plates are to be installed.
- 3. Inspect arm for cracks.
- 4. "V" any cracks.
- 5. Weld cracks with 7018 low hydrogen rod.
- 6. Weld reinforcing gussets to side plates.
- 7. Inspect welds for cracks.
- 8. Prime and paint new metal.

If you have any questions, contact Wisdom Industries, Ltd. at 970-522-7515.



EXTENDED POSITION



LOADING POSITION

SIDE VIEW

5/16 MCHPLATE



