

A.R.M., INC 1506 Fernwood Rd. Wintersville, OH 43953 740.264.6599 740.266.2953 Fax Bulletin No: SB070113 Release Date: July 1, 2013 Effective Date: July 1, 2013

Supercedes: N/A

Completion Date: Aug 1, 2013

Page: 1 of 18

SERVICE BULLETIN

Manufacturer: A.R.M., Inc.
Ride Name: Vertigo A

Model(s): 100 / 200 / 300
Affected Production Dates: July, 2009 - June, 2013

AFFECTED SERIAL NUMBERS

ABSTRACT OF ISSUE

A MANDATORY modification of existing sweep assemblies to provide a redundant support for the carriage swivel block in the unlikely event the primary hanger pin fails or is unintentionally dislodged during operation.

REASON FOR RELEASE

The Vertigo Sweep Modification was developed as a precautionary measure only. There are no known failures of a primary hanger pin and there have been no reported cases of the pin becoming dislodged. This mandatory modification addresses concerns expressed by owners and/or State jurisdictions and has been developed to avoid licensing issues in such jurisdictions.

ACTION TO BE TAKEN

Installation of support members, or "cups", to each sweep as detailed in the attached installation instructions. All necessary components are included in A.R.M., Inc kits **#VM0162**, **#VM0163**, **#VL0132** & **#VL0133**. The appropriate kit will be determined when ordering based on production number.


All work to be completed by competent personnel capable of understanding the function of the modified components and the proper procedures for installation.

Welding shall be in accordance with the appropriate American Welding Society or the American Society of Mechanical Engineers, or other equivalent standard, and be performed by an appropriately certified or qualified welder as required by the standard.

DETAIL OF ISSUE

This modification requires the addition of two **Safety Cups** to each Vertigo sweep to act as a redundant support for the **Carriage Swivel Block**.

An Interlock Pin is also added to ensure the Swivel Block remains seated.



NOTICE

ONLY COMPONENTS SPECIFIED, AUTHORIZED, OR PROVIDED BY A.R.M. (US), INC. SHALL BE USED A.R.M. (US) INC. SPECIFICALLY DISCLAIMS ANY LIABILITY ASSOCIATED WITH THE USE OF UNAUTHORIZED COMPONENTS OR MODIFICATIONS AND/OR ALTERATIONS OF AUTHORIZED COMPONENTS.

100 SERIES

VG101-07-01-09 VG102-07-01-10 VG103-05-21-11 VG104-04-01-12 VG105-08-01-12

200 SERIES

VG201-01-30-10 VG202-03-13-10 VG203-05-01-10 VG204-06-10-10 VG205-08-15-10 VG206-08-15-10 VG207-01-29-11 VG208-07-20-11 VG209-01-05-12

300 SERIES

VG301-03-05-11 VG302-10-1-11 VG303-01-05-12 VG304 VG305

VERTIGO CARRIAGE SUPPORT REDUNDANCY KIT

For Kits #VM0162, #VM0163, #VL0132, & #VL0133

For Field Installation On All Vertigo 100, 200 & 300 Models Produced Prior To June, 2013

All Work To Be Performed By Competent Personnel Capable Of Understanding The Function Of The Modified Components And The Proper Procedures For Installation.

Welding To Be Perfomed By A Certified Welder.

Purpose:

This modification is designed to provide a redundancy for the passenger carriage attachment to the end of the sweep in the unlikely case of a **PRIMARY HANGER PIN** failure.

Should the **HANGER PIN** fail, the **CARRIAGE SWIVEL BLOCK** will drop approximately 1/8" and be reatined by the cup and the **INTERLOCK PIN**.


Compliance Date:

The manufacture date of of compliance is Aug 1, 2013. However, individual State regulations may require immediate installation prior to operation in such juristictions.

Certification Of Compliance:

Upon completion, please complete the Certification Of Compliance below and remit this page to A.R.M., Inc. via postal mail, fax or e-mail.

ARM, Inc. 1506 Fernwood Rd. Wintersville, OH 43953 740.266.2953 FAX mike@armrides.com




CERTIFICATION OF COMPLIANCE


The Vertigo Seat Carriage Support Redundancy Kit Described Herein Has Been Installed Per The Included Instructions. All Welding And Inspection Has Been Performed By A Certified Welder.

Ride Serial#:	
Compliance Date:	
Signature:	
Printed Name:	


	NAME	DATE	ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953				
DRAWN	DMM						
APPROVED			PROPRIETARY AND CONFIDENTIAL				
Print Date: Tuesday, July 02, 2	2013						
MATERIAL			SIZE Part No.			REV	
			Α		Install Sweep Weldment		
DO NO	OT SCALE DRAW	ING					

5 ' 2 ' 1





- □ Place Cup/Hole Template As Illustrated. Ensure Indicated Faces Are Flush.
 Use Seat Hanger Pin And Clamps To Keep Template In Position
- ☐ Remove paint and debris from area to welded. Clean and prep for proper weld.




Page 5 of 18



DRAWN APPROVED Print Date: Tuesday, July 02, 201	NAME DMM	DATE		ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL				
MATERIAL			SIZE	Part No.		REV		
DO NOT	SCALE DRAWI	ING	A		Install			

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

- □ Place Cup Material As Illustrated Using The Template To Determine Position.
- □ Tack Weld Cup In Position




Page 6 of 18



DRAWN APPROVED Print Date: Tuesday, July 02, 20	NAME DMM	DATE	ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL				
MATERIAL		SIZE	Part No.		REV		
DO NOT SCALE DRAWING		A		Install			
<u> </u>							

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\






DRAWN	NAME DMM	DATE		ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953				
APPROVED			WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL					
Print Date: Tuesday, July 02, 201	13							
MATERIAL	MATERIAL		SIZE	Part No.	REV			
			Α	Install				
DO NOT SCALE DRAWING								

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

5

- ☐ Reposition Template To Outside Of The Side Plate As Illustrated.
- □ Drill 5/16" Hole Through Side Plate Using Template To Locate Position.
- □ Remove Template And Redrill Hole To 9/16"




Page 8 of 18



DRAWN	NAME DMM	DATE		ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953				
APPROVED			PROPRIETARY AND CONFIDENTIAL					
Print Date:								
Tuesday, July 02, 20	13							
MATERIAL			SIZE	Part No.		REV		
			Α		Install			
DO NOT	SCALE DRAW	ING						


\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

- □ Reposition Template To Inside Of The Opposite Plate As Illustrated.
- □ Drill 5/16" Hole Through Side Plate Using Template To Locate Position.
- □ Remove Template And Redrill Hole To 9/16"




	NAME	DATE		ARM MFG., INC.				
DRAWN	DMM			1506 FERNWOOD RD. WINTERSVILLE, OH 43953				
APPROVED			PROPRIETARY AND CONFIDENTIAL					
Print Date: Tuesday, July 02, 2013								
MATERIAL			SIZE	Part No.	REV			
			Α	Install				
DO NOT	CON E DEVIN	NC.	1					

\\DESIGNII\Data\Solids\Vertigo 200\Seat Safety Back-Up\







Page 11 of 18



104263 Style B Cup/Hole Template



104261 Cup

	NAME	DATE	
DRAWN	DMM		
APPROVED			
Print Date:			

DO NOT SCALE DRAWING

ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL

Tuesday, July 02, 2013

MATERIAL

Part No.


REV

1

Install **Sweep Weldment**

\\ DESIGNII\ Data\ Solids\ Vertigo 200\

- □ Place Cup/Hole Template As Illustrated. Ensure Indicated Faces Are Flush
 Use Seat Hanger Pin And Clamps To Keep Template In Position.
- □ Remove paint and debris from area to welded. Clean and prep for proper weld.




Page 12 of 18




DRAWN APPROVED Print Date: Tuesday, July 02, 20:	NAME DM M	DATE		ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL			
MATERIAL			SIZE	Part No.	REV		
DO NOT	SCALE DRAW	ING	A	Install Sweep Weldment			

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\







	NAME	DATE
DRAWN	DMM	
APPROVED		
Print Date:		

Print Date: Tuesday, July 02, 2013 MATERIAL

IVII (TETA) (E

SIZE

Part No.

Install Sweep Weldment

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

DO NOT SCALE DRAWING

2


ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL

REV

5

Page 13 of 18

☐ Move Template To Opposite Plate And Repeat Procedure To Position And Tack Cup



Page 14 of 18

REV

NAME DATE ARM MFG., INC.

DRAWN DMM 1506 FERNWOOD RD.
WINTERSVILLE, OH 43953
PROPRIETARY AND CONFIDENTIAL

Print Date: Tuesday, July 02, 2013

MATERIAL

SIZE Part No.

Install Sweep Weldment


1

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

5

DO NOT SCALE DRAWING


- □ Reposition Template To Outside Of The Side Plate As Illustrated.
- Drill 5/16" Hole Through Side Plate Using Template To Locate Position.
- □ Remove Template And Redrill Hole To 9/16"



	▄
	▋▗
	— `
	= σ
	■z
	█▋』
	■*


DRAWN APPROVED	NAME DMM	DATE		ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL				
Print Date: Tuesday, July 02, 201	13							
MATERIAL	MATERIAL		SIZE	Part No.		REV		
DO NOT	OO NOT SCALE DRAWING		A		Install Sweep Weldment			

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\



□ Drill 5/16" Hole Through Side Plate Using Template To Locate Position.

□ Remove Template And Redrill Hole To 9/16"





DRAWN	NAME DMM	DATE	ARM MFG., INC. 1506 FERNWOOD RD. WINTERSVILLE, OH 43953 PROPRIETARY AND CONFIDENTIAL		
APPROVED					
Print Date: Tuesday, July 02, 2013					
MATERIAL			SIZE	Part No.	REV
DO NOT	SCALE DRAW	ING	A	Install Sweep Weldment	

\\ DESIGNII\ Data\ Solids\ Vertigo 200\ Seat Safety Back-Up\

