



Number: B376R1003-0

Date: 5/25/86

Supersedes:

SERVICE BULLETIN

Effective Serial Numbers: ALL UNITS

Ride: YO YO

Subject: Chair Hanger Wear Limits

As a safety precaution, CHANCE RIDES, INC. recommends that the following inspection be performed on all YO YO amusement rides at every set-up or weekly, whichever occurs first.

The inspection must be performed by competent personnel, capable of understanding the function of the parts and their proper installation.

Measure the edge distance on all chair hangers as shown. If the dimension is less than .313 (5/16"), do not operate the ride until the chair hanger is replaced.

New chair hangers are available from CHANCE RIDES, INC. Order part number 361-32706.

