

518.

SBF-Visa Taxi ride support arm cracking

NAFLIC has been informed by a UK inspection body that during the inspection of an SBF-Visa Taxi ride crack indications were found in two of the five support arms ends. The indications are not visible without the aid of MPI. The arms are used to keep the ride gondolas level when the main arms lift. The image below is an example of this ride type.



You can see the support arms in the image above. They are the red bars located under the main blue arms. The cracks were found on both the outside and inside of the arm end Gab, the point where the small levelling arm pins to the bottom of the seating. (See accompanying images on the following page).

The information contained within is provided in good faith and every effort has been made to ensure its accuracy. NAFLIC shall not be held responsible for any loss of business or profits, nor any direct or indirect or consequential loss or damage resulting from the publication/distribution and/or use of the information provided or any inaccuracy herein.

